


Size conversion chart in centimeters

How to measure

2. Measure horizontally around the fullest part of your chest, under the armpits with your motorcycle gear on.
3. Measure horizontally around your abdominal, at its deepest body point with your motorcycle gear on.
4. Measure the circumference, from pelvic bone to pelvic bone, at the widest part of your hips.
5. While standing upright, measure the distance between the lower neck and the tailbone.
9. Measure from the floor to the top of your head.

The cartridge size must fit the airbag size.



Size	XS	S	M	L	XL	L-L	XL-L
Height (9)	145-165	155-170	165-175	170-185	180-195	170-185	180-195
Chest (2)	60-85	80-95	85-100	90-105	95-110	100-115	105-130
Waist (3)	60-75	70-80	75-85	80-90	85-95	90-115	100-125
Hips (4)	65-80	80-95	85-100	90-105	95-110	100-115	105-130
Back length (5)	30-45	45-55	50-60	55-65	60-70	55-70	60-75
Cartridge	60cc	60cc	60cc	60cc	60cc	100cc	100cc